



MAINTENANCE PREVENTIVE / PREVENTIVE MAINTENANCE

REP-LOT	QT	NB	DESIGNATION	/	DESIGNATION
012A-012A	1	0120067000N	CHEMISE-TIROIR	/	CONTROL SPOOL ASSY
434B-434B	1	4340031151N	CIRCLIPS	/	CLIPS
439-439	1	4390044030N	ROULEMENT ABILLES	/	BEARING
-A	1	3050900230F	LOT DE JOINTS	/	SET OF SEALS
434A-A	2		CIRCLIPS	/	RETAINING RING
438-A	3		JOINT TORIQUE	/	ORING
438A-A	2		JOINT TORIQUE	/	ORING
-J	3	4370013051N	HUILE HYDROMECHANIQUE	/	HYDROMECHANICAL OIL

MAINTENANCE CORRECTIVE / CORRECTIVE MAINTENANCE

REP-LOT	QT	NB	DESIGNATION	/	DESIGNATION
012-012	1	0120105006N	PISTON	/	PLUNGER
052A-052A	1	0520009001N	ROUE EXCENTRIQUE	/	ECCENTRIC WHEEL
068-068	1	0680040006N	AXE EXCENTRIQUE	/	ECCENTRIC SHAFT
-B	1	3050564350F	ENSEMBLE CLAPET	/	CHECK VALVE ASSEMBLY
023-B	1		VIS	/	SCREW
080-B	1		RESSORT DE COMPRESSION	/	COMPRESSION SPRING
212A-B	1		CLAPET DE SECURITE	/	POPET RELIEF VALVE
-C	1	30751110001F	ENS.DOIGT DACCROCHAGE	/	CATCH FINGER
214A-C	1		DOIGT ACCROCHAGE	/	HOOKING PIN
435-C	1		VIS CHC	/	SCREW CHC
435E-C	1		ECROU	/	NUT
435F-C	1		VIS HC	/	SCREW HC
-D	1	3050564340F	ENS.AXE/BIELLE	/	PIN/CONNECTING ROD ASSY
011-D	1		AXE DE BIELLE	/	WIRST PIN
214-D	1		BIELLE	/	CONNECTING ROD
-E	1	3050009010F	ENSEMBLE REGLAGE MANUEL	/	HAND ADJUST ASSEMBLY
243-E	1		CHEMISE	/	PLUNGER CYLINDER
253-E	1		ECHELLE DE DEBIT	/	OUPUT SCALE
253A-E	1		GRADUATION	/	SCALE
255-E	1		BOUTON DE REGAGE	/	CONTROL KNOB
256-E	1		VIS ARRET	/	SCREW
434-E	1		SEGMENT ARRET	/	CLIPS
-F	1	3051152130F	ENS. REDUCTION	/	REDUCTION ASSEMBLY
052-F	1		VIS SANS FIN	/	WORM SCREW
052A-F	1		ROUE EXCENTRIQUE	/	ECCENTRIC WHEEL
432D-F	1		BOUCHON	/	PLUG
434B-F	1		CIRCLIPS	/	CLIPS
435A-F	1		VIS SANS TETE	/	SCREW WITHOUT HEAD
439-F	1		ROULEMENT ABILLES	/	BEARING
-G	1	3075010013F	LOT DE BOUCHON	/	SET OF PLUGS
432-G	1		BOUCHON	/	PLUG
432B-G	1		BOUCHON DE REMPLISSAGE	/	FILLING PLUG
432C-G	1		INDICATEUR DE NIVEAU HUILE	/	OIL LEVEL INDICATOR
-H	1	3075110012F	ENSEMBLE CARTER DE BASE	/	HOUSING ASSEMBLY
012-H	1		PISTON	/	PLUNGER
081-H	1		CARTER	/	HOUSING
402-H	1		BOUCHON	/	PLUG
432-H	1		BOUCHON	/	PLUG
432B-H	1		BOUCHON DE REMPLISSAGE	/	FILLING PLUG
432C-H	1		INDICATEUR DE NIVEAU HUILE	/	OIL LEVEL INDICATOR
434A-H	2		CIRCLIPS	/	CLIPS
438-H	3		JOINT TORIQUE	/	ORING
438A-H	2		JOINT TORIQUE	/	ORING
-I	1	3075110015F	ENS.VIS SANS FIN	/	WORK ASSY
052-I	1		VIS SANS FIN	/	WORM SCREW
434B-I	1		CIRCLIPS	/	CLIPS
439-I	1		ROULEMENT ABILLES	/	BEARING
-K	1	3051153100F	ENSEMBLE MONTAGE MOTEUR	/	MOTOR MOUNTING ASSEMBLY
025-K	1		JOINT	/	SEAL
434C-K	4		RONDELLE	/	WASHER
435B-K	4		VIS H	/	SCREW H